



USER GUIDE SUMMARY

Full Set	Enter Your Code	?? ??
	Press Full	FULL
Part Set	Enter Your Code	?? ??
	Press Part	PART
Unset	Enter Your Code	?? ??
Omit Zones	Enter Your Code	?? ??
	Press Full or Part	FULL or PART
	Press Omit	OMIT
	Press Zone Number(s)	?...
	Press Prog	PROG
Reset	Enter Your Code	?? ??
	Press Reset	RESET
Chime Set	Enter Your Code	?? ??
	Press Chime	
	Press Zone Number(s)	?...
	Press Prog	PROG
Chime Unset	Enter Your Code	?? ??
	Press Chime	
	Press Reset	RESET
Test Sounders & Strobe	Enter Your Code	?? ??
	Enter 00	00
	Enter 05	05
	Press 4, 3, 2, 1 in turn	4 3 2 1
	Press 0	0
	Press Reset	RESET
Walk Test	Enter Your Code	?? ??
	Enter 00	00
	Enter 06	06
	Conduct Walk Test	Conduct Walk Test
	Press Reset	RESET
Code Change	Enter Existing Code	?? ??
	Enter 00	00
	Enter 01	01
	Enter New Code	?? ??
	Press Prog	PROG
	Press Reset	RESET